



Installation Instructions

JLT Draw Through Air Box (2011 Mustang GT 5.0 w/ Vortech or Paxton Supercharger) #JLTAB-FMGPVDT-11

***DO NOT INSTALL KIT AND DRIVE WITHOUT A TUNE! ***

Please review complete instructions prior to installing.

Step#	
1	Verify you have all of the following parts included in the kit: (1) JLT 110mm MAF housing, (1) 4.5-4" reducer, (2) Clamps (1) 4.5x9 Air Filter, (1) Heat Shield, (2) MAF screws (1) nut
2	Gather all of the following tools needed for the installation: 5/16 nut driver, 10mm socket, ratchet, extension, T-20 torx driver, Phillips head screw driver
3	Remove the stock airbox by loosening the clamp at the blower tube and removing the 10mm bolt in airbox. Unplug the MAF (if used) and remove box from vehicle.
4	Install the JLT heat shield by slipping it under the air inlet duct, lining the front hole up with the stud on the fan shroud and secure it with the supplied nut, then use the stock airbox bolt to secure it to the car.
5	Remove the stock MAF sensor from your airbox using the T-20 torx driver and install in the JLT MAF housing using the supplied screws. It will only install one way.
6	Install reducer – MAF – Filter on the tube coming from the blower and installation is complete.



This kit includes an S&B Powerstack pre-oiled reusable air filter. The frequency you should clean your filter will depend on your driving conditions. It is recommended to check your filter at every oil change or 3,000 miles. If there is a build up of dirt as thick as the wire mesh, then it's time to clean your filter. As dirt builds up on your filter, the restriction of the airflow also increases. More frequent cleanings will improve your fuel economy and your vehicle's performance.

To properly clean your filter, we recommend the S&B Precision Cleaning & Oiling Kit (located in the Parts Sold Separately Section of our website, www.JLTtruecoldair.com).

Thanks for the business. If you have any questions, please e-mail Jay@JLTtruecoldair.com or call 757-335-1940. Our hours are Monday-Friday, 8:00am – 5:00pm Eastern Time.

Warranty: JLT Performance Inc. will repair or replace any part of their product found upon our inspection to be defective in workmanship or material within 1 year from the purchase date for the original purchaser.

Disclaimer: JLT Performance Inc. makes no warranties whatsoever, expressed or implied, oral or written to any purchasers, except the warranty above. JLT Performance Inc. hereby specifically excludes from any implied warranty of merchantability or implied warranty of incidental, secondary, or consequential damages of any kind whatsoever. All purchasers and users of products manufactured by JLT Performance Inc. agree to hold harmless and indemnify JLT Performance Inc. from any and all claims arising from their use. Failure to receive notice of any or the limitations contained in this disclaimer shall not serve to extend liability to JLT Performance Inc. for any claims arising out of use of its products.

Return Policy: All returns will be subject to a 10%-25% restocking fee. Air Filters will not be accepted for return unless they are in original plastic sealed bag. Please visit www.JLTtruecoldair.com for complete return policy.