



Carbon Fiber Strut Tower Caps 2015-2017



Wash the Strut Towers with soap and water. Allow the strut towers time to dry. **Recommended: Wipe the Strut tower down with isopropyl alcohol to ensure the cleanest surface possible.



Before removing the tape backing, test fit the part. The notches align with the strut nuts/studs. Peel the tape backing and install.