

MODERN BILLET

Stainless Steel Rocker Panel Trim w/ Mustang Logo 2015-2017



Wash the rocker panels with soap and water. Allow the panel and surrounding areas time to thoroughly dry.



Wipe the panel down with isopropyl alcohol to ensure the cleanest surface possible. Allow the panel time to dry.



Test fit the trim panel on the rocker panel. Apply the supplied adhesion promoter to the panel underneath the trim panel. Allow the adhesion promoter to dry to a haze. Then peel off the tape backing.



Place the trim panel on the rocker panel. Apply firm even pressure to the trim panel to ensure proper adhesion.