



Contents:

- (1) Left GT Style Vents
- (1) Right GT Style Vent
- (2) Rolls of 3M Double Sided Tape

GT Style Hood Vents
(15-17) V6, EcoBoost EXC. GT and GT350



1

Wash the hood with soap and water. Allow the panel time to dry. ****Recommended:** Wipe the mounting surface down with isopropyl alcohol to ensure the cleanest surface possible.



2

Apply the supplied 3M tape. Test fit the part on the hood to familiarize yourself with how the part should fit.



3

Measure from the front edge and side edge of the hood to ensure the louver is in the same place on both sides. Mark around the edges of the louver to ensure the louver is placed in the correct position. Remove the 3M tape backing and install. Apply firm even pressure to ensure proper adhesion.