

# MP CONCEPTS

## 15-17 Black Decklid Panel

REQUIRED Panel Removal Tool 1/4 Metric Socket Set  
Flat Screw Driver



1 Using a panel removal tool, remove the caps covering the deck lid panel bolts. Then, remove the (4) 7mm screws.



2 Use the panel removal tool to gently separate the factory deck lid panel from the deck lid.



3 Unplug the reverse camera. Then remove the panel from the vehicle. **\*\*Note Reverse Camera will be removed and reinstalled on to the MP Concepts panel.**



4 Remove the factory (4) push clips across the top of the decklid panel. Transfer the clips to the MP Concepts panel



5 Remove the factory (4) screw clips across the bottom of the decklid panel. Transfer the clips to the MP Concepts panel



6 Install the MP Concepts Decklid panel to the car, and push the panel up engage the clips. Then fasten the (4) 7mm screws to bolt the decklid panel in place.