

MP CONCEPTS

Contents:
(1) Left Winglet
(1) Right Winglet
(1) Roll 3M Tape

REQUIRED:
Basic Hand Tools
Panel Removal Tool

GT350 Style Rear Bumper Winglet (15-17 Premium Bumpers exc. GT350)



Remove the (3) fender liner clips and fold the fender liner out of the way.



Thoroughly clean the back side of the bumper cover to remove any and all wax/grease. ****Note:** Use isopropyl alcohol to ensure the cleanest possible tape surface.



Using a 7mm socket, remove the (2) bolts securing the bumper cover to the bumper bracket. ****Note:** This hardware will be used when installing the winglet.



Apply the supplied 3M tape to the winglet surface as shown above.



Peel off the tape backing prior to installing the winglet.



Using the factory hardware, bolt the winglet to the vehicle. Apply firm even pressure to the taped surface to ensure proper adhesion.