

Contents:

- (1) Left Winglet
- (1) Right Winglet
- (1) Roll 3M Tape

REQUIRED:

Basic Hand Tools

Rear Bumper Winglet (15-17 Premium Bumpers exc. GT350)



Front under the vehicle, remove the (2) bumper push clips.
****Note:** These clips will be reused. Thoroughly clean the bottom edge of the bumper trim to remove any and all wax/grease. ****Note:** Use isopropyl alcohol to ensure the cleanest possible tape surface.



Apply 3M tape the to winglet surface as shown above.



Peel off the tape backing prior to installing the winglet.



Install the winglet using the factory push clips. ****Note:** There are a tight fit but they will press all the way in. Apply firm even pressure to the taped surface to ensure proper adhesion.