

## 15-17 Carbon Fiber Interior Panels (Performance Pack Models Only)



Step 1 // Thoroughly clean your interior panels so that they are free of any dirt or silicone based interior dressings. It is highly recommended to use isopropyl alcohol to ensure the cleanest possible surface prior to installing the carbon fiber overlays.

Step 2 // Begin by test fitting all the overlays so that you know where they go. They will be secured to the existing interior panels using a double sided tape.

Step 3 // Once you are comfortable with where the panels go and how they will install, remove the tape backing.

Step 4 // Carefully place the carbon fiber overlay on the appropriate panel. Apply Firm even pressure to the overlay to ensure proper adhesion.