

15-17 Carbon Fiber Engine Cover

Required: Basic Hand Tools



Begin by removing the engine cover. Firmly pull on the corners to dislodge the cover from its rubber mount. ****Note:** If equipped with factory strut tower brace remove the (4) 15mm bolts securing the brace to the vehicle.



Place the Carbon Fiber Engine Cover onto the motor. Apply pressure to ball mount location to clip the cover into the rubber mounts. Reinstall strut tower brace in reverse order.