

Modern Billet Chrome Brake Fluid Cap Cover / Tri-Bar Logo (05-14 V6 & GT)

Time Required: 5min

Tools Required:

- ✓ 2.5mm Allen Wrench / Hex Key
- ✓ Cleaning Cloth

Part:

Brake Fluid Cap Cover



Safety:

- (1) Engage Emergency Brake or insure in Park for Automatics.
- (2) Make sure engine is off and cool.

Preparation and Install:

- (1) Open Hood and Clean Existing Plastic Brake Fluid Cap



- (2) Remove 3M Tape and press Cap Cover onto Plastic Brake Fluid Cap



(3) Use Allen Wrench / Hex Key to tighten both mounting screws



Complete



Installation Instructions written by AmericanMuscle Customer Mitch Smith 07.20.14