

Chrome Door Lock Pins (05-13)

Tools Required:

- No tools required but you may want to have a cloth to remove dust if there is any when you remove the old pins

Time Necessary: Under 10 mins.



Pre-installation

Installation:

1. Remove the existing lock pin by simply turning it with your hand in a counter-clockwise direction.



2. Once the old pin is removed it should look like the picture below.



3. Take the new chrome pin and install it by turning it in a clockwise direction with your hand.



4. Ensure that the pin is able to go up and down smoothly and lock your vehicle without any issues.



5. Repeat the process for the other door





Post installation

Installation Instructions written by AmericanMuscle customer A. Lara 10.22.12