

Modern Billet Chrome Oil Dipstick Handle (05-14 V6)

Tools Required:

- Hand Saw
- Razor Blade
- 5/32 Drill Bit and Drill
- Allen Key Set
- Ruler



STEP 1. Measure from the base of the dipstick handle up 5/8" and mark the handle for cutting.



STEP 2. Using a small hand saw, cut the top of the handle off where you previously marked it and trim the sides to be square in shape.



STEP 3. Using the handle for reference, mark the factory handle for drilling.



STEP 4. Using a 5/32 drill bit, drill a hole for the retaining screw to pass through.



STEP 5. Slide the t-handle over the factory handle and insert the retaining screw into place to hold the two halves together.