

## Chrome Vent Louvers (10-14 All)

**Time Necessary:** Under 10 mins.

**Tools Required:**

- ✓ Needle nose pliers or flat head screwdriver
- ✓ Soft cloth or towel (to protect the door sill and the old louvers)



*Required Tools*



*Pre-installation area with factory louvers*

**Installation:**

1. Use your pliers or screwdriver to remove existing louvers by simply pulling up and away from the doorsill. Be careful not to damage the doorframe or louvers with your tool by using a soft cloth to prevent direct contact.



2. Clean any debris or dust out of the area where the new louver will be inserted.



3. Line up the new chrome louver with the opening left after removing the factory louver.



4. Push down firmly until the chrome louver clicks and locks into place. Repeat the process on the other door panel.



***Post installation***

Installation Instructions written by AmericanMuscle customer A. Lara 4.2.13