

Tail Light Trim (2010+):

No Tools Required!

Installation Tips: Make sure you have a clean dry work area.

BEFORE:



Installation Instructions:

1. Clean tail lights with mild soap and water and dry thoroughly.
2. Test fit tail light trim – Do not remove tape yet.
3. Use the included alcohol pad to clean the outside area of tail lights.
4. Carefully remove red adhesive covering on one tail light trim piece.
5. Slowly press trim piece onto the tail light, making sure edges fit. It helps to press down gently on one side first, giving you an opportunity to move the trim piece if needed.
6. If satisfied with fit and placement, press down firmly on outside edges to adhere to tail lights.
7. Repeat with other side.
8. Gently pull on trim pieces to check for adhesion. If adhesive gives, repress firmly on edges.

9. You're done! Wipe off any finger prints and enjoy!



Installation Instructions written by AmericanMuscle customer Norman Smith 3.13.12