

## Installation Instructions for Raxiom Switchback Turn Signal Conversion Kit

### Step 1:

Remove headlights/turn signal from vehicle if connectors are not easily accessible

### Step 2:

Locate the parking light connector and remove socket from light housing

### Step 3:

Find the signal wire and the ground wire on your vehicle.

87-93:

Signal – White with Blue Stripe

Ground – Black

1999-2004:

Signal – Green

Ground – Black

2005-2009:

Signal – Gray with Black Stripe

Ground – Black wire

2010-2014:

Signal – Blue with Green Stripe

Ground – Black with Yellow Stripe



(2010-2014 Shown above)

### Step 4:

Using the supplied splice in connectors, attach one connector to the signal wire and one to the ground.



### Step 5:

Install the spade connectors onto the resistor wires and plug into the splice-in connectors you attached in Step 4 (orientation not important).



### Step 6:

Securely mount the resistor to the vehicle being sure to avoid moving parts. The resistor can put out a lot of heat, be sure to keep away from other wiring.

### Step 7:

Reinstall the headlights/turn signals into the vehicle to complete the installation.