

Raxiom LED Tail Light Conversion Kit (05-09 All)

Tools Required:

- Adjustable Wrench
- Flathead Screwdriver



Installation:

1. Open Trunk
2. Using a Flathead Screwdriver remove the two tabs on each side of the trunk latch.



3. Remove the two plugs on each side of the trunk's liner by the trunk's opening.



4. Remove the plastic trunk liner to provide you with room to work.
5. Remove the three nuts holding the driver's side taillight housing in place. You can use your fingers to remove the nuts however if the nuts are little tight you can loosen them up using an adjustable wrench.



6. Once all of the nuts are removed you can gently remove the taillight housing from its place. While removing the housing be careful not to scratch the rear bumper.
7. The three numbered plugs show below are the plugs containing your taillight bulbs. Carefully twist each one of these to get to the old bulbs.



8. Carefully pull the bulb out of the socket to remove it and replace each bulb with a new LED bulb.



9. Once each bulb is replaced with a new LED bulb carefully put the socket with the LED bulb back into the housing and twist the socket back into the housing.
10. Replace the taillight housing back into the car. (Don't put the nuts back on yet as testing is still necessary.)
11. Repeat above steps on passenger side taillight.

Testing:

1. Step into the vehicle and turn the lights on. (Key does not need to be in the ignition for this.)
2. Exit the vehicle and take a look.
3. If all of the LEDs are on and look like they do below congratulations you are all done you may turn the lights off and secure the nuts on the back of the taillight housing in the trunk.



If one or more bulbs are not on:

1. Make sure lights are off.
2. Remove LED from socket. Rotate LED 180 degrees.
4. Turn lights on and test again.

Installation Instructions Written By AmericanMuscle Customer Zach Petruzzi 10/23/2013