



## PANHARD RELOCATION MOUNT

Part # PHR008

Approximate Install time – 1 hour

### REQUIRED TOOLS:

- 18mm and 15mm sockets
- Ratchet
- Hydraulic jack and stands (optional if not using service lift)

### INSTALLATION:

1. Lift vehicle with suspension loaded. This may be done using a 4 post service lift or by backing the car up onto ramps.
2. Remove the plastic Panhard rod cover as shown in Image 1.
3. Remove the drivers' side lower shock bolt using a 15mm socket.
4. Remove the drivers' side panhard rod mounting bolt and lower the panhard rod down, out of the mount.
5. Position the BMR relocation bracket into the mount as in Image 2.
6. Lift the panhard rod up, into the BMR mount and insert the provided 14mm bolt. Do not tighten.
7. Compress the shock until it lines up with the mounting hole and slide the factory bolt through the BMR relocation bracket and into the factory mounting holes.
8. Tighten the 14mm Panhard rod bolt with a 22mm socket to 129 ft/lbs. Tighten the shock bolt to 85 ft/lbs.
9. Lower vehicle.



**WWW.BMRFABRICATION.COM**

*This product is an aftermarket accessory and not designed by the vehicles manufacturer for use on this vehicle. As such, buyer assumes all risk of any damage caused to the vehicle/person during installation or use of this product.*