

OEM Headlight w/ Foglight Switch (87-93 All)

Tools Required:

- ¼ RATCHET
- 7MM SOCKET
- 8MM SOCKET
- STANDARD PHILLIPS SCREWDRIVER



Installation Instructions:

- 1.) If you look underneath the steering column, you'll find two small holes, in which you'll use the Phillips to take out the screws. Once those screws are out, you should be able to easily remove the column.





- 2.) Once the column is out, you should be able to remove the knee guard, but if you look on the bottom of the guard you'll find three screws which are 8mm. Take all the screws off and safely remove the knee guard to make sure you don't crack the plastic. Next will be the metal knee plate; which also has two 8mm screws holding it in place. Remove those and place plate aside.





- 3.) When the metal plate is removed, remove the two 7mm screws from the top of the dashboard and gently remove to prevent cracks in the plastic. Next, you'll have to remove the two clips holding the headlight/foglight switch. Once that is done you, can pull the switch right out of the dashboard by unclipping it from the wiring harness.





- 4.) Install the new headlight/foglight switch and make sure it's properly functioning. Once that is complete, you can start putting your dashboard back together.
- 5.) Plug the new switch in and attach it again using the two clips. At this point you can test to make sure the switch is working.
- 6.) Reattach the switch fascia to the dash and screw in all of the removed trim panels.



Installation Instructions written by AmericanMuscle customer Joseph Kirk 9.11.12