

Polished Billet Interior Complete Kit (94-04 All)

Tools Needed:

- Supplied allen wrenches
- Pliers

Note:

This is a pretty easy install, not much needed other than the supplied tools and maybe 45mins of your day.



Install Instructions:

1. Starting with the door pins, simply unscrew your old ones and screw on the new billet ones. If the old ones are tight just use your pliers to help.



- For the cruise control buttons just stick your finger behind and pull them off. Then take your new ones and snap them in place. The right side is in two pieces, take the bottom half off first.



- The A/C knobs are probably the easiest of all. Just pull them off and push on the new ones.



4. Next let's do the emergency brake, start by loosening the two screws on the bottom with your supplied allen wrench.



5. Then drop the button in and hold on to it from the outside while sliding the handle over your existing handle. (this will be a tight fit but with some twisting it will go all the way down)



6. Tighten the two screws and your done with this part.
7. The tilt wheel handle is another easy one. Just unscrew the old and replace with your new one. Again if the old one is stuck and won't unscrew just use some pliers to help.



8. For the turn signal cover, loosen the one screw with your supplied allen and place it over your turn signal then tighten down the screw. Do not over tighten, keep in mind its plastic underneath.



9. Finally the last thing to do is your headlight knob. Start by pulling it out as if turning on your headlights and turning it so that the slot faces out.



10. You'll see inside this slot there is a small metal plate. Use your supplied allen wrench to pull this plate back while simultaneously pulling on the knob. Should just slide right off.

11. Loosen the one small screw on your new one and place it on. Tighten the screw all the way down and you're good to go.



12. Step back and admire your new Polished Billet Aluminum accents of your Mustangs' interior!



Installation Instructions written by AmericanMuscle customer Isaiah Cook 1.31.2014