



P/N S197-510-A Made in USA

2005-09 Tru-Billet Automatic Shifter Bezel Installation Instructions

Thank you for your purchase of SilverHorse Racing products. Please read all directions before beginning the installation. A factory shop manual should be available for reference during installation. If, after reading these and any accompanying directions, you feel that you may not be able to complete the installation safely and properly, please seek out professional installation by certified technicians. Please read and understand our product purchase agreement (included on yellow sheet) prior to starting installation. Vehicle should be off with key removed from ignition and in park with parking brake set prior to beginning installation.

Tools Needed:

Flat Screwdriver or plastic wedge for removing trim

Safety glasses

1. Gently pry up on the OEM plastic bezel and remove avoiding damage to the center console top area.

2. Lower the new shifter bezel into place. The fit between the shifter housing and the bezel's inner surfaces should keep the bezel in place with no additional steps. However, on a small number of 2008+ Mustangs with the black shifter, a small amount of 3M VHB double-sided tape may be required to insure proper fit. This is due to varying tolerances on the black shifter on 08+ cars.



3. Installation is complete !!

If you have any questions, feel free to contact us at the number listed below or via email.

Tech Questions: (321)-722-2813.

Email us -

Tech@SilverHorseRacing.com

“If it’s not good enough for our cars, we won’t make it for yours.”

