



P/N S197-555

Door Lock Pin Installation Instructions

Thank you for your purchase of SilverHorse Racing products. Please read all directions before beginning the installation. A factory shop manual should be available for reference during installation. If, after reading these and any accompanying directions, you feel that you may not be able to complete the installation safely and properly, please seek out professional installation by certified technicians. Please read and understand our product purchase agreement (included on yellow sheet) prior to starting. Vehicle should be off with key removed from ignition and in park (if applicable) with parking brake set prior to beginning installation.

Expected installation time is 5 minutes for a first-time installer.

TOOLS / MATERIALS REQUIRED:
None Required

1. Place vehicle in park / set parking brake, turn off vehicle, and open doors one at a time.
2. With factory door pins in the unlocked position, grab by hand and unscrew stock pins in a counter-clockwise direction.
3. Grasp new door lock pin, and gently start threading onto lock rod in clockwise direction.
4. Continue turning clockwise until Tru-Billet replacement lock pin bottoms out on rod. Tighten snugly, but do not over-tighten.
5. Repeat for other side. Enjoy!

If you have any questions, feel free to contact us at the number listed below or via email.

Tech Questions: (321)-722-2813.

Email us -

Tech@SilverHorseRacing.com

“If it’s not good enough for our cars, we won’t make it for yours.”

