

## CoverCraft Bra (94-98 GT, V6)

**Time Necessary:** Approximately 1 hour

**Tools Required:**

None

**Preparation:**

1. Remove front license plate
2. Wash the front end of the car

**Installation:**

1. Open the hood and slide the hood piece of the bra over the hood. Secure the nose piece by strapping one side to the other.





2. Stick one Velcro strip on each side of the upper grille as shown in the picture below.



3. Attach the top two pieces of the bra to these Velcro strips.



4. Take the two remain Velcro strips and attach one on each side of the car to the inside of the fender under the hood. The picture below shows exactly where they need to be placed. Then stick the bra to these strips.



5. Now install one curved Velcro piece on each fender in the wheel well.



6. Pull the bra up and bend the top tab of the bra around the Velcro strip you just installed. Then bend the remaining two lower tabs around the wheel well and repeat this step on the other side.



7. Install the 5 hooks on the straps hanging off the bottom of the bra.



8. Attach the 5 hooks to the underside of the bumper and pull each strap snug. The pictures below show the locations I choose to attach the hooks.



Passenger's side



Center



Drivers Side

9. Finally make minor adjustments the tension on the lower straps so the bra is evenly stretched over the nose then line up your license plate and screw it back in place through the bra.

Don't worry about the wrinkles from the bra being folded in the box; these will come out after a few days.



**Before**



**After**

Installation Instructions Written By AmericanMuscle Customer Brandyn Johnson 10/30/2013