

Covercraft UVS100 Heat Shield - Tri-Bar Pony Logo (05-09 All)

Installation Time: Five minutes

Difficulty Level: Easy.

Tools: Not required.



Note: Sun screen may not reach all the way to windshield pillars for full black out. This additional space is required for installation and removal without damaging your sun screen.

Installation Instructions:

1. Unfold sun screen with reflective foil side facing outward and place flat onto dashboard.



2. Slide past defroster vents to the bottom of windshield.
3. Lift sun screen with both hands in to place

4. Pull down passenger side visor then drivers side to hold firmly in place.



Removal Instructions:

1. Simply reverse the installation steps, fold the unit and store in the trunk, under seat, or behind passenger seat.

Optional Storage bag may be purchased to protect sun screen while storing.

