

SR Performance Throttle Body Spacer (05-10 V6)

Tools Required:

- ✓ 8mm Ratchet
- ✓ 10mm Ratchet
- ✓ Extension for the Ratchet
- ✓ Flat Screwdriver (or however to get the cold air intake off)

Installation Time: 10-20min

BEFORE:



Installation Instructions:

1. Disconnect the negative side of the battery .



2. Disconnect the cold air intake from the throttle body. If you have large hands and want more room, disconnect the entire cold air intake.

3. Unscrew the (4) 8mm bolts on the throttle body.



4. Slip the throttle body spacer in between the throttle body and the plenum. Make sure the longer side is facing to the passenger side.



5. Insert the (4) new throttle body bolts into the throttle body and spacer. I started with the top so I do not have to worry about alignment on the bottom where it is hard to see.



6. Attach the intake onto the throttle body.



7. Enjoy your new throttle body spacer!

Installation Instructions written by AmericanMuscle customer Nathan Peterson 4.30.12