

Speed Of Sound Dual Gauge Pillar - Charcoal (10-13 All)

Tools Required:

- None

Installation Instructions:

1. Look at the boring OEM Pillar and Open the driver's side door.



2. Carefully, begin pulling down on the OEM pillar. There are a total of five clips that hold the factory pillar in. Remove the OEM pillar completely and put it away. Note that at the bottom corner of the pillar, there are two hooks. Be sure to take it easy pulling it out and notice where the holes are.





3. If you are installing gauges, now would be the time to run the wires and install the gauges into the pods.
4. Line up the front end of the SOS Pillar towards the bottom of the windshield, making sure any wires/hoses from the Gauges you installed are properly tucked away inside and not showing, and making sure the hooks on the SOS pillar go into the slots.



5. Push in all five clips.

6. Make sure everything lines up correctly, and the SOS pillar is secured to the car and doesn't move.
7. Enjoy your new SOS Pillar!



Installation Instructions provided by AmericanMuscle customer Ricardo Iglesias 12.19.12