

## Installation Instructions for JLT PCV Pre-Filter

Included parts: Pre-Filter Body / Metal Filter / 2 Grommets / 1 fitting

### 1999-04 Mustang GT 4.6:

Driver side: \*USE SMALLER GROMMET INCLUDED IN THIS KIT\*

Pull stock hose from fitting on valve cover. Install Pre-Filter onto the fitting Grommet side first and reinstall PCV hose as shown. Oil on grommet and hose will help install.



### 1996-04 Cobra & MACH I:

Passenger side: \*USE LARGER GROMMET INCLUDED IN THIS KIT\* Pull out hose and fitting from grommet in valve cover. Screw Pre-Filter into grommet, screw 90 degree fitting into Pre-Filter and reconnect hose as shown:



### 1999-04 Lightning:

Driver side: \*USE SMALLER GROMMET INCLUDED IN THIS KIT\*

Pull stock hose from fitting on valve cover. Install Pre-Filter onto the fitting Grommet side first and reinstall PCV hose as shown. Oil on grommet and hose will help install.



### 2003-04 Marauder:

Driver side: \*USE SMALLER GROMMET INCLUDED IN THIS KIT\*

Remove fitting and hose from valve cover grommet. Insert Pre-Filter and re-install hose and fitting into Pre-Filter.

If you are using this on a vehicle or side not listed, you will need to find your own grommets, fittings and hose to make it work.

Thank you for the business. If you have any questions, please e-mail [jay@JLTtruecoldair.com](mailto:jay@JLTtruecoldair.com) or call 757-335-1940. Our hours are 8:00am – 5:00pm Eastern Time.