

Billet A/C Knob Installation Guide (1987 - 2006)



The below installation instructions work for the following products:

- 1999-2004 Mustang Polished AC Knobs
- 2005-2006 Silverhorse Racing Satin Climate Control Knobs
- 2005-2006 Silverhorse Racing Chrome Climate Control Knobs



Once again, another simple install for something that makes your interior much more classy!

Tools Required:

- Fingers and Muscles

This installation will take you about 5 minutes to do.

1. Grab onto your stock A/C Knobs.
2. Pull hard to remove it.
3. Then pop the new knob into place. It is easiest to take the knobs and turn them all the way to the left or right, so that you can line up your new knobs properly.
4. Do this for each knob.
5. Check and make sure your knobs are able to turn freely.

Note: Ford changed the design of the A/C knobs for the 2007+ model years

Find more **how-tos**, **instructions** and **videos** at www.americanmuscle.com!