

**Step 6:**

Spray the transfer tape with the solution. The solution will help with the release of the tape.

**Step 7:**

After the solution has been squeegeed out from under the decal and the transfer tape has been wet for about ten minutes start to remove the tape. Pull the tape slowly at a sharp angle back

**Step 8:**

Once the tape is off you can use a squeegee (covered in a cloth that will not scratch the vinyl and keep the vinyl wet) if you need to, but at this point you may need to use a pin or needle to release any bubbles, squeegeeing on vinyl that has been stuck to the surface may wrinkle instead of moving air from underneath the vinyl.

**Step 9:**

Use a sharp razor blade to cut any excess vinyl at the wheel well opening and either cut it flush or tuck it inside the wheel well as shown. Also cut the stripes between the door gaps and wrap the ends around the door and body.

**Step 10:**

Generously spray the lower quarter panel with the soap & water solution and lay the vinyl down using the side marker light cutout as a guide.

**Step 11:**

Follow steps 6 through 9 for the quarter panel part of the decal

Leave several hours, depending on climate, of dry time before cleaning car. Use a quick detailer in a spray bottle for the initial cleaning then hand wash car waiting at least several days for the first time after drying. ***Do not power wash vinyl or wax vinyl.***

## ***Installation Instructions for Side Stripes (2005+)***



**Customer Service: 1-866-727-1266**