

Bumper Insert Letters - Installation Instructions



The below installation instructions work for the following products:

- Mustang Cobra Stainless Steel Bumper Insert Letters (96-98 & 01)
- Mustang Stainless Steel Bumper Insert Letters (94-98 GT and V6)
- Mustang Black Steel Bumper Insert Letters (99-04 Mustang GT and V6)
- Mustang Black Chrome Bumper Insert Letters (99-04 Mustang GT and V6)
- Mustang Stainless Steel Bumper Insert Letters (99-04 Mustang GT and V6)
- Mustang Cobra Stainless Steel Bumper Insert Letters (03-04)



Please read through the instructions carefully before starting this project. Take the time to get all the materials together as well as all the safety equipment.

Installation:

1. Use the supplied alcohol prep pads to carefully clean bumper where letters will be inserted.





2. Peel the 3M bonding tape from each letter and place carefully in correct slot in bumper. Take care to align letters properly during installation because the 3M bonding tape is difficult to remove once applied.





3. Peel back and remove protective film from inserts.



4. Repeat above steps for remaining letters and enjoy your new Mustang Stainless Steel Bumper Inserts!



Installation instructions provided by Stack Racing

Find more **how-tos**, **instructions** and **videos** at www.americanmuscle.com!