

## Chrome Mustang Mirror Covers (05-09) - Installation Instructions



The below installation instructions work for the following products:

- **Chrome Mustang Mirror Covers (05-09)**
- **Chrome Mustang Exterior Door Dress-Up Kit (05-09)**



Please read through the instructions carefully before starting this project. Take the time to get all the materials together as well as all the safety equipment.

### **Installation:**

1. Use the alcohol pad included and clean the surfaces where the mirror cover will be affixed to your mirror.



2. Before applying the covers, make sure all of the backing is completely removed from the 3M bonding tape.



3. Once the backing tape is removed, position the covers on the mirrors to insure they are aligned properly. Take care not to press down on the trim during this step.



4. When you feel you have successfully lined the covers up with the form of the mirror, press firmly along the entire surface of the covers to ensure a complete and sturdy bond is made with your mirror.



5. Repeat all four steps for the second cover piece on the opposite mirror to finish the installation.



Installation instructions provided by Manufacturer

Find more **how-tos**, **instructions** and **videos** at [www.americanmuscle.com](http://www.americanmuscle.com)!