

Mustang Chrome Underhood Dressup (86-98) - Installation Instructions



The below installation instructions work for the following products:

- **Chrome Mustang Windshield Washer Reservoir Cap Cover (86-97)**
- **Chrome Mustang Radiator Reservoir Cap Cover (86-89)**
- **Chrome Mustang Radiator Reservoir Cap Cover (90-95 5.0L)**
- **Chrome Mustang EGR Valve Cap Cover (87-93)**
- **Chrome Mustang EGR Valve Cap Cover (96-98)**
- **Chrome Mustang EGR Valve Cap Cover (99-04)**
- **Chrome Mustang Wiper Motor Cover (87-93)**



Please read through the instructions carefully before starting this project. Take the time to get all the materials together as well as all the safety equipment.

Installation:

1. Be sure your engine is turned off and cooled down.
2. Carefully clean and dry the original cap..
3. At this point, if your cover came with it, remove the protective sheet off the double-sided adhesive tape on the back of the new chrome cover.
4. Slip the new cover onto your original cap.
5. If the cover is loose, we recommend you put a small piece of masking tape on the outer lip of the original cap, so it will stay secure.
6. To clean simply us a damp cloth, window cleaner or mild chrome polish.

Installation instructions provided by Paul E. Karp

Find more **how-tos**, **instructions** and **videos** at www.americanmuscle.com!