

Mustang Convertible Wind Deflector (05-10) - Installation Instructions



The below installation instructions work for the following products:

- **Mustang Convertible Wind Deflector (05-10)**



Please read through the instructions carefully before starting this project. Take the time to get all the materials together as well as all the safety equipment.

Installation:

1. Remove windstop from storage bag and place over rear trim panels as shown.



2. On each side of the car, take tie-down strap and hook under bottom of trim next to rear seat.
3. Here is the bottom of the trim where to hook the the tie-down strap.



4. Once hooked under, use the velcro strip to cinch the tie-down strap tightly so that there is no movement in the windstop.





5. The convertible top can be raised or lowered with the windstop in place.

Installation instructions provided by Manufacturer

Find more **how-tos, instructions** and **videos** at www.americanmuscle.com!