

Covercraft Mustang Pocket Pod (99-04) - Installation Instructions



The below installation instructions work for the following products:

- **Covercraft Mustang Pocket Pod (99-04)**



Please read through the instructions carefully before starting this project. Take the time to get all the materials together as well as all the safety equipment.

Tools needed:

- Hardware Kit (included)
- 6 Pushpin Fasteners (included)

Installation:

1. With trunk open, determine the alignment for the pocket pods by matching the unit to the contour of the trunk.



2. Next, check the hole alignment for the pocket pods by matching them with the holes on the trunk lid.



3. Insert the (6) kit supplied pushpin fasteners through the mounting holes on the unit. Line up the pushpin fasteners with the holes and firmly press them into place.





Installation instructions provided by Covercraft

Find more **how-tos**, **instructions** and **videos** at www.americanmuscle.com!