

AMERICAN MUSCLE GRAPHICS

Customer Service: 1-866-727-1266

Installation instructions for Hood Decal

Tools Required:

Spray bottle with soap & water mixture
Plastic Squeegee
Pair of scissors
X-Acto knife or razor blade
Painters tape
Surface cleaner-Mequiars Deep Crystal System paint cleaner
Needle or pin

Prep:

Clean car well to ensure good adhesion of the decal. Remove any wax from the area using a surface cleaner. Fill a spray bottle with a mixture of soap and water (we use baby shampoo), about 4 large drops per 32 oz. spray bottle of water. Be sure to install decal out of direct sunlight. Also having one to assist you if you can is very helpful.


Step 1:

Spray hood with a generous amount of the soap and water mixture.



Step 2:

Peel backing from insert exposing the adhesive. Also spray back of decal as your peeling the backing paper off.



Step 3:

Place insert on hood (for 99-04 place it up against the plastic scoop trim). You will be able to maneuver the insert into position because of the soap and water solution you sprayed on earlier

Step 4:

Once you have the insert in its final position, use the plastic squeegee to push any air bubbles towards the outer edges.

Step 5:

Then spray the transfer tape with the solution generously. This will soften the adhesive to let the transfer tape be removed easier. The transfer tape at this point will look more transparent.



Step 6:

Squeegee out any remaining air bubbles from the center out



Step 7:

Once you have all of the air bubbles out and stripes have dried underneath, slowly peel the transfer tape from the decal. Pull the tape as flat on the car as possible this will help prevent the tape from pulling up the vinyl. One trick that may be helpful is to place a squeegee on the transfer tape and peel it back against the squeegee while holding the squeegee down on the decal keeping it tight on the tape that's being pulled.



Step 8:

Once the tape is off you can use a squeegee (*covered in a cloth that will not scratch the vinyl and keep the vinyl wet*) if you need to, but at this point you may need to use a pin or needle to release any bubbles, squeegeeing on vinyl that has been stuck to the surface may wrinkle instead of moving air from underneath the vinyl.



Matte black hood decal without transfer tape

Step 1:

Spray hood with a generous amount of the soap and water mixture.



Step 2:

Peel backing from insert exposing the adhesive. Also spray back of decal as you peel the backing paper off.



Step 3:

Place insert on hood (for 99-04 place it up against the plastic scoop trim). You will be able to maneuver the insert into position because of the soap and water solution you sprayed on earlier.



Step 4:

Squeegee out the water from underneath the decal with a squeegee (*covered in a cloth that will not scratch the vinyl and keep the vinyl wet*).



Vinyl that needs to conform to curves of the hood can be pressed into place with your hands or if need be the use of a hair dryer to help conform to the shape of the car. Also when tucking vinyl around the edges of the car. ***Do not over heat it will shrivel or wrinkle.***

Leave several hours, depending on climate, of dry time before cleaning car. Use a quick detailer in a spray bottle for the initial cleaning then hand wash car waiting at least several days for the first time after drying. ***Do not power wash vinyl or wax vinyl.***