

## Mach 1 Chin Spoiler Installation Guide



The below installation instructions work for the following products:

- **Ford Mustang Mach 1 Chin Spoiler 1999-2004**



Please read, review, and understand the provided installation instructions before starting the installation of the chin spoiler. If you don't you risk damage to your front fascia, as well as the destruction of your chin spoiler!

### Parts Needed for Install:

- Chin Spoiler
- Push Pin Fasteners (10)

### Tools required:

- Masking tape or Duct Tape
- Drill
- 1/4" Drill Bit

### '94-'04 Mach 1 Chin Spoiler Install

1. Raise front of vehicle using ramp, hoist, or by using a jack with jackstands. **DO NOT ATTEMPT TO INSTALL THIS IF YOU ARE NOT USING JACKSTANDS! SERIOUS INJURY CAN RESULT!**
2. Take the chin spoiler and line it up flush with the edge of the wheel well. Tape the Chin Spoiler in place so that it stays and you can drill the holes that will be used for the push pin fasteners that will hold the spoiler in place.
3. Once the chin spoiler is taped into place, check fit along front edge.  
**Note:** Chin Spoiler will be flush with the fascia for about 4 to 5" from wheel opening then it goes behind the leading edge of the fascia.
4. When Spoiler is evenly spaced on fascia, drill 1/4" holes into fascia at each Chin Spoiler screw location. Insert pushpin fasteners into the fascia to secure the chin spoiler to the fascia. It's easiest to insert them right after you drill.
5. Remove tape.
6. Flaunt your car.

Find more **how-tos**, **instructions** and **videos** at [www.americanmuscle.com](http://www.americanmuscle.com)!

