

Moroso Mustang Polished Aluminum Valve Covers (260, 289, 302, 351W) - Installation Instructions



The below installation instructions work for the following products:

- **Moroso Mustang Polished Aluminum Valve Covers (260, 289, 302, 351W)**



Please read through the instructions carefully before starting this project. Take the time to get all the materials together as well as all the safety equipment.

Breather Hole Removal :

1. Position the Valve Cover topside down on a surface that will not scratch or mar the finish of the Valve Cover.
2. Make a center-punch mark in the Breather Hole you will be removing. (Some Moroso Valve Covers already have this mark). Use a hole saw to drill a 1-3/16" hole through the Valve Cover.
3. Use a round file to increase the hole diameter to approximately 1.22" and to remove any flashing.

Installation instructions provided by Moroso

Find more **how-tos, instructions** and **videos** at www.americanmuscle.com!