

How to Install a Pony Delete Billet Grille for a 1994-1998 Mustang



The below installation instructions work for the following products:

- [Polished Mustang Pony Delete Billet Grille \(94-98\)](#)
- [Black Pony Delete Billet Grille \(94-98 GT, V6\)](#)

Here at American Muscle, we're all about DIY (do it yourself). Of course, there's nothing wrong with seeking out a little bit of tech help prior to taking on an installation on your own. Our Mustang installation guides will provide valuable instructions and hopefully answer any how-to questions that you may have along the way.

Preparation

Please read through the instructions from start to finish before starting this project. If you can access the rear of your lower grille from underneath your car without raising it, you should be able to complete this project; otherwise, you will have to lift the rear.

Tools needed:

- Small Socket and Wrench Set
- Needle Nose Pliers
- Wire Cutters

Optional Tools

- Droplight or other Portable Lighting Source
- Jack and Jackstands (or safe alternative)
- Electrical Tape

Installation:

1. If your car's setup prevents you from accessing the rear of the lower grille, use your preferred method for raising the front of your car to gain access.
2. An additional set of hands will be very useful for this installation. Center the grille insert in the bumper opening. Note that you may need to bend the billet bars lightly to align with your particular car's fit.
3. From the back of the grille, slide the two provided clips over the back of the upper lip of the lower grille opening. Space them about 1/3 of the way between the edge of the opening and the center bar.



4. Center your grille. Have your assistant hold the grille in place. From the back of the grille, thread the two provided wires through the front of the grille, wrapping them around the side bars of the grille.



- Twist the wires until the **grille** is held securely in place. Trim excess wire with the wire cutters and wrap the ends of the wires in electrical tape to prevent scratching your paint.



- Check to make sure your grille is centered.
- Congratulations, you're finished. Enjoy your new billet grille from Stack Racing.



94-98 Upper Billet Grille (No Pony) Installation

1. Remove the radiator shroud. Release the clips holding the shroud in place.



2. To remove the pony and it's bracket, simply unscrew the 2 Philips head screws that are holding it to the vehicle.



3. Center your new grille in your hood opening, and have your assistant hold the grille while you mark the location of the 3 brackets: One top center, and 2 lower side brackets. (A metallic marker, nail polish, or a sharp scribe will all work.)



4. Using a 3/16" bit, drill a pilot hole in each of the locations you marked above.



5. Attach grill by using supplied hardware. Tighten using hand tools. DO NOT USE POWER TOOLS IN THIS STEP, as it may damage your Mustang's plastic grill shell. Also, make sure not to over-tighten your hardware.

NOTICE: If your Mustang was produced between 1-94 and 6-95, in order to prevent interference with the grille and insure easy opening of your hood, you may need to update your hood latch to the later style used in cars provided from 7-95 through your Ford dealership, using part # F6ZZ-16700-AA.