

AMERICAN MUSCLE GRAPHICS

Installation Instructions for Vinyl Bumper Insert Letters

Tools Required:

Spray bottle with soap & water mixture

Prep:

Clean car well to ensure good adhesion of the decal. Fill a spray bottle with a mixture of water and soap (we use baby shampoo), about 4 large drops per 32 oz. spray bottle of water. Be sure to install decal out of direct sunlight.

Step 1:

Spray bumper with a generous amount of the soap and water mixture.



Step 2:

Peel letters from adhesive sheet and place them in the inserts on the bumper. Spraying them with solution as you peel can help from getting the decal stuck to itself. Otherwise be careful not to let the decals fold and stick to themselves as you go.

Step 3:

Once you have the letters properly aligned, push any air bubbles out towards the edges with your fingertip.



Leave several hours, depending on climate, of dry time before cleaning car. Use a quick detailer in a spray bottle for the initial cleaning then hand wash car waiting at least several days for the first time after drying. **Do not power wash vinyl or wax vinyl.**

Customer Service: 1-866-727-1266