

Mustang Rear Decklid Panel (05-09) - Installation Instructions



The below installation instructions work for the following products:

- **Mustang Rear Decklid Panel (05-09)**



Please read through the instructions carefully before starting this project. Take the time to get all the materials together as well as all the safety equipment.

Installation:

1. Using the supplied alcohol prep pads, thoroughly clean the rear decklid where the adhesive strips from blackout panel will be applied.





2. Peel the backing from the adhesive strips on the rear of the blackout panel.



3. Place blackout panel over rear decklid using center pony emblem as a reference point. Make sure that blackout panel is centered and extends evenly to both sides of decklid. Also take care to ensure that corners meet top edge of decklid on both sides and follow contour of factory tail lights.





4. When blackout panel is properly aligned, firmly press down on adhesive strips to fully seat blackout panel.



Installation instructions provided by Manufacturer

Find more **how-tos**, **instructions** and **videos** at www.americanmuscle.com!