



**P/N S197-525-05**

**2005-06 Tru-Billet Climate Control Knob Installation Instructions**

Thank you for your purchase of SilverHorse Racing products. Please read all directions before beginning the installation. A factory shop manual should be available for reference during installation. If, after reading these and any accompanying directions, you feel that you may not be able to complete the installation safely and properly, please seek out professional installation by certified technicians. Please read and understand our product purchase agreement (attached) prior to starting installation. Expected installation time is 10 minutes.

<b>TOOLS / MATERIALS REQUIRED:</b>	
Allen Wrench (included)	Safety Glasses (wear during installation)
Pliers (optional)	

1. With the vehicle off, in park or neutral and with the parking brake set on a flat, level surface, begin by turning all three controls to the 12 o'clock position. Grasp the knobs firmly one at a time with pliers if needed, and pull straight away from the head unit, being careful to not dislodge the shifter or accidentally release the emergency brake. Slight wiggling from left to right may aid in removal.

2. Install new knobs, aligning flat of D-clip with flat on shaft. Push firmly until knob surface is flush with climate control face and rotating freely like original knobs. Test for proper operation. If knob can be pulled off too easily, slight adjustment of the set screw using supplied allen wrench may be required. Do not overtighten, as this can damage the clip.



Installation is complete!

**If you have any questions, feel free to contact us at the number listed below or via email.**

**Tech Questions: (321)-722-2813.**  
**Email us -**  
[CustServ@SilverHorseRacing.com](mailto:CustServ@SilverHorseRacing.com)

**“If it’s not good enough for our cars, we won’t make them for yours.”**



**MEMBER**