

Mustang 3rd Brake Light & Quarter Light Trim (05-09) - Installation Instructions



The below installation instructions work for the following products:

- **Chrome Mustang Quarter Light Trim (05-09)**
- **Chrome Mustang Third Brake Light Trim (05-09)**
- **Black Mustang Third Brake Light Trim (05-09)**
- **Black Mustang Quarter Light Trim (05-09)**
- **Chrome Mustang Brake Light Dress-up Kit (05-09)**
- **Black Mustang Brake Light Dress-up Kit (05-09)**



Please read through the instructions carefully before starting this project. Take the time to get all the materials together as well as all the safety equipment.

Installation:

1. Use the alcohol swab included and clean the surfaces where the trim will be adhered to the light. Allow the car to sit in the shade for about 20 minutes to cool the surface before installation.





2. Before applying the trim, make sure all of the backing is completely removed from the 3M bonding tape .



3. Once the backing tape is removed, carefully line the trim up with the outer edge of the light. Take care not to press down on the trim during this step.



4. When you feel you have successfully lined the trim up with the grooves of the light, press firmly along the entire surface of the trim to ensure a complete and sturdy bond is made with your light.



5. If applicable, repeat all three steps for the additional trim pieces on the remaining lights to finish installation.
6. Enjoy your new Mustang light trim!

Installation instructions provided by Manufacturer

Find more **how-tos**, **instructions** and **videos** at www.americanmuscle.com!