

Stack Racing Chrome Mustang Strut Tower Brace (05-10 GT/V6) - Installation Instructions



The below installation instructions work for the following products:

- **Stack Racing Chrome Mustang Strut Tower Brace (05-10 GT/V6)**



Please read through the instructions carefully before starting this project. Take the time to get all the materials together as well as all the safety equipment.

Tools Required

- 3/8" Drive Ratchet and 13mm Socket or 13mm Wrench

Installation:

1. Remove eight strut mount nuts as shown below with a 13mm socket or wrench.





2. Place strut bar over strut mount studs and re-install 13mm nuts removed in Step 1.





Installation instructions provided by Stack Racing

Find more **how-tos, instructions** and **videos** at www.americanmuscle.com!