Justin's Performance Center
301 Serendipity Drive
Millersville, MD 21108
www.JPCracing.com
866-JPC-RACE

HARD LINE/SOLENOID INSTRUCTIONS

WARNING:

- ***Failure to disconnect negative battery lead could result in damage to your cars electrical system***
- ***When raising a car to access the undercarriage always use a jack stand***
- ***Brake fluid can damage your vehicles painted surfaces***
- ***Always check brake lines for leaks***
- ***Always Test Brake system before you road test the car.***

1. Unpack your JPC Line lock. Check all parts to make sure all parts on the item list are in the box and seem to be in working condition.

2. Disconnect the negative battery end.

3. Remove the Air box to gain access to the brake lines.