



INSTALLATION INSTRUCTIONS

#70-3232 05-10 FORD MUSTANG LONG TUBE HEADERS

NOTE: Before beginning installation, be sure that vehicle is firmly supported by jack stands or ramps of sufficient load capacity for the weight of the vehicle. **NEVER** go under a vehicle which is supported only by its service jack.

INSTALLATION PROCEDURE:

1. Disconnect battery. Raise vehicle and support with jack stands or ramps of sufficient load capacity for the vehicle.
2. Disconnect all four O2 sensor connectors and remove H-pipe. Remove starter. Unbolt steering coupler at steering rack. Remove left side steering rack mounting bolt and loosen right mounting bolt. Pry rack forward to disengage steering shaft from steering rack. Do not allow steering wheel/shaft to turn while disengaged.
3. Raise engine and remove motor mount brackets. Support engine in this position.
4. Remove exhaust manifolds. Remove exhaust manifold studs.
5. Remove dipstick and dipstick tube. Remove chassis stiffener bar.
6. Clean gasket surfaces on cylinder heads. Apply a high temperature gasket sealer such as Permatex Ultra-Copper on gaskets supplied with kit. Install new headers with new bolts supplied in kit.
7. Torque header bolts from center out in stages. Final torque should be 18 ft.lbs.
8. Re-install dipstick tube. Install the ½" bushing between the dipstick tube bracket and cylinder head so that the dipstick tube will clear the header flange.
9. Reinstall motor mount brackets.
10. Guide the steering coupler onto the steering rack post while prying the rack back into place. Reinstall the left side mounting bolt and torque both mounting bolts. Reinstall and torque the steering coupler bolt.
11. Reinstall starter. Reinstall chassis stiffener.
12. Loosely install the O2 sensors into the bungs on header collectors and measure the length of wire extensions that will be necessary. Extend the O2 sensor harnesses per instructions, install sensors and reconnect.
13. Header installation is complete, ready for exhaust system.
14. Remove jack stands and lower vehicle. Re-connect battery and start engine.
15. Check for exhaust leaks, rattles, clearance problems. Correct if necessary.

NOTE:

There may be some lubricant left in the tubes from the mandrel bending process. You may smell this lubricant burning off for the first few days of using your new headers. This is normal and will cause no harm and will disappear. After a few days of operation, check all fasteners and clamps. Retorque as necessary.